
SEQUENCE CONTROL PANEL WITH SOLAR SYSTEM
CONTROLLER ILC-131-ETH
INLINE FUNCTION TERMINAL-IB-IL-RS-UNI-PAC
WIRELESS MODULE RAD-2400-IFS
ANTENNA -RAD-ISM-2400-ANT-OMNI-6-0
ANTENNA CABLE-RAD-PIG-RSMA/N-3
POWER SUPPLY UNIT-TIRO-PS-2G/1AC/24DC/5
JUNCTION BOX MASTER SIDE
LAPTOP FOR SCADA OPERATION
RECEIVER WIRELESS MODULE
SOLAR CELL
BATTERY
SOLAR JUNCTION BOX
JUNCTION BOX SLAVE SIDE
WIRELESS TRANSCEIVER-RAD-IFS-2400
I/O EXTENTION MODULE-RAD-DO8-IFS
ANTENNA-ANT-DIR-2459-01
ANTENNA CABLE-RAD-PIG-RSNA/N-3
POWER SUPPLY UNIT -TRIO-PS-2G/1AC/24DC/5
RELAY BOARD OF 10 CHANNELS 24VDC
8CORE 1.5SQMM AR.CU. CABLE
JUNCTION BOX
3CORE 1.5SQMM AR.CU. CABLE
SB 1
SB 2
SB 3
SB 4
SB 5
SB 6
SB 7
SB 8
SB 9
SB 10
SB 21
SB 22
SB 23
SB 24
SB 25
SB 26
SB 27
SB 28
SB 29
SB 30







CROSS SECTION OF COAL STOCK PILE